

# ROD REMOVING EQUIPMENT

In most situations drive rods and multi-piece drive rod sets can be removed from the ground easily by hand. Occasionally however, they can become stuck. We have developed a range of tools to make the removal process quick and simple.



## ROD REMOVERS

Rod removers are used to remove drive rods in light and medium installations.

Slide both rod removers onto the drive rod and pull upwards until the entire drive rod has been extracted from the ground.

